

IGT SLANT TOP SIDE PANEL

K626-DP



1. Open access door to bill validator area
2. Unplug power cable going to lamp of glass panel in open door as shown
3. Remove housing assembly and discard
4. Install new LED panel assembly using the same method (see illustration)
5. 19" models: Route cable toward the back of the machine, to the left and up thru the upper glass panel display area. (17" models plug into I/O port).
6. Plug cable into unused connector on power buss printed circuit board.
7. Close up panels and LED display will light up.

Danger: 12 volt dc assembly

